



CONVEX

GEARWRAP

THICK, RUGGED MEDIA THAT FITS TO CURVES

HOW TO APPLY HELMET DECALS



www.CONVEXvinyl.com ■ orders@graphicms.com
order online at www.shopGMS.com ■ 847.582.9276 ■ 800.232.8018

HELMET DECAL | APPLICATION

SAVE TIME AND \$\$\$ FOLLOWING THESE IMPORTANT DETAILS

- 1) Start with a clean, dry helmet surface, and clean fingers before applying a CONVEX decal.
- 2) Before peeling the liner (backing) from the CONVEX decal, make sure to align the decal on the helmet to get an idea of exactly where you want it. You can use a crayon or pencil to mark where the edges are going to be and wipe it off later. Peel the liner off the decal and don't let it stick to itself.
- 3) Take your time, position the CONVEX decal, and stick the center down to the helmet first.

EASILY AFFIX HELMET DECALS WITH THESE SIMPLE STEPS



STEPS 1 & 2

STEPS 1 & 2: Slide your thumbs from the center out to the edges sticking the decal to the helmet. The top and bottom should still be curling up as shown in the photo here.

STEPS 3 & 4: Slide your thumbs or fingers up (3) and down (4) pressing the decal onto the helmet.

Now stop.

You should now see "air tunnels" in the shape of funnels between where you rubbed the decal down.

STEPS 3 & 4



IMPORTANT LAST STEPS (5-8): Rub from the center of the decal out to the edge, and rub down the center of the air tunnel (see diagram above). This will create two narrower air tunnels on each side of the one being rubbed out. In a few steps all the air tunnels will have disappeared!

Take your time. If you try to rub a big air tunnel out quickly, it can condense the vinyl too much. This will result in the vinyl pushing up from the helmet. The finished decal should be clean, professional looking, and without puckers. Any air bubbles will dissipate. With patience and practice, you can become a PRO!